178 West Greystone Road • Old Bridge NJ 08857 USA

Tel: 732-251-0800 Fax: 732-251-9442

SUPERIOR MODEL 10, 15, 20, 25 S/L GASOLINE POWERED BLOWER PARTS

Part #	Item Description
501	Plawer Housing Model 20, S/I *
502	Blower Housing Model 20-S/L* Blower Housing Model 10-S/L**
502	Blower Wheel
503	Blower Shaft
505	Set of (2) Wheel Shaft Bearings w/ Bearing Collars
506	Pair of Base Angle Brackets
507	•
509	Fiberglass Blower Base w/ Rubber Gasket Under
510	Blower Carrying Handles 3 ½ hp Briggs & Stratton Gasoline Engine
510	3" Engine Pulley
512	8" Fan Pulley (Standard)
513	Pulley Guard (No Belts)
513A	Standard Drive V-Belt
513B	High-Output Drive V-Belt
513B 518	Alternate Pulley Kit
519	Fluid Conversion Kit for 10/15/20/25 -S
523	Micro Control Valve with Connector
524	Fluid Injector Nozzle
525	Copper Tubing with Fittings (for Fluid System)
527	Pump Bottle w/ Hose & Connectors
537	Pump Bottle Hose w/ Quick Connector
538	Smoke Conversion Chamber for 10/15/20/25-L
542	Pair of Handle Support Brackets
543	Rubber Gasket for Base (2 piece)
544	Fuel Tank for Gas Engine
545	Micro Control Valve Bracket
546	Brass Quick Connect Female (connects to hose)
547	Brass Quick Connect Male (connects to valve)
548	Brass Quick Connect Set (male & female)

^{* 20-}S/L Blower Housing Includes: Blower wheel, blower shaft, 2 wheel shaft bearings with bearing collars, smoke bomb rack, auxiliary outlet with cover, slide damper, pair of base angle brackets, brackets for handles, and damper handle.

^{** 10-}S/L Blower Housing Includes: Blower wheel, blower shaft, 2 wheel shaft bearings with bearing collars, smoke bomb rack, pair of base angle brackets, and handle brackets.